



FLEXIBLE PARTIAL

Cleaning and Maintaining

1. DAILY CLEANING

Greater "C" recommends cleaning your appliance daily using an over-the-counter denture cleaner. It is also suggested that you rinse after meals to remove any food particles.

2. USING CLEANING AGENTS

Only use a soft bristle brush and scrub gently to avoid damage.

3. CAUTIONS

- NEVER use any abrasives, such as toothpaste or powdered cleansers, to clean your appliance.

4. MAINTAIN

Contact your dental professional if you experience any discomfort. Your dental professional will advise you when you come in for a regular checkup.