



# SOFT LINERS

*Cleaning and Maintaining*

## 1. DAILY CLEANING

Greater "C" recommends rinsing your denture after every meal. Clean once a day using denture cleanser and an "extra soft" bristle tooth brush.

## 2. USING CLEANING AGENTS

Soaking your denture up to 10 minutes in a denture cleanser is typically adequate.

## 3. CAUTIONS

- DO NOT SOAK your appliance in cleansers "overnight".
- NEVER scrub the soft liner with a hard bristle denture brush. This will damage the special protective vinyl sealer on the surface of the soft liner.

## 4. MAINTAIN

To prolong the life of your Soft Liner, visit your Dental Professional every six months to reapply a vinyl sealer.